ASSEMBLY INSTRUCTIONS

CROWNMARK: B4300-1 DRESSER


(BOX 1) BOX OF DRESSER


NO	ITEM	QTY
A	DRESSER	1 PC

(BOX 1) HARDWARE LIST

NO	ITEM	QTY
1	Truss Head Machine Screw m4x28mm Blk	7 PCS
2	HANDLE	7 PCS

STEP 1: Remove HANDLE (2) using a Philips head screw driver as shown in illustration STEP - A. Re-install the HANDLE (2) as per diagram STEP - B. Repeat STEP - A STEP - B until HANDLE (2) are attached correctly.





NOTE: MUST TIGHTEN SCREWS PERIODCALLY OR SCREWS WILL BECOME LOOSE.CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.

ASSEMBLY INSTRUCTION

CROWNMARK: B4300-1/B4300-11 DRESSER & MIRROR

STEP 1

STEP 2: Align & fasten mirror support (B) to the back of mirror (A) using short JCBC bolt(1),spring washer (2) & flat washer (3). DO NOT FULLY TIGHTEN AT THIS STEP.

Note: Make sure arrow marking of the mirror support (B) is aligned up.

(Box 1)

BOX OF MIRROR


A ITEM Qty

MIRROR

1 PC

B 2 PCS

Take out mirror support (B) from the carton box.



**BACK VIEW


(Box. 2)
BOX OF DRESSER



STEP 3: Place mirror (A) on top of dresser (C). Align & fasten mirror support (B) to the back of dresser (C) using long JCBC bolt (1), spring washer (2) & flat washer (3) THEN FULLY TIGHTEN ALL THE BOLTS AT STEP 2 & 3 WITH ALLEN KEY (4).

(Box. 1) HARDWARE LIST





Note: Make sure arrow marking of the mirror support is aligned with the arrow marking of the center of the dresser as shown in drawing.

